



ORG5321

Instructions for Preprinted Yellow Simplified Final-stage Certification Labels

The labels (with the exception of trailer labels) must be placed next to the driver's side of the vehicle at the following locations:

- (a) Hinge pillar,
- (b) Door latch post, or
- (c) Door edge that meets the door latch post.

If none of these positions is available, the label can be placed on either the:

- (a) inward-facing surface of the driver's door, or
- (b) left side of instrument panel.

The final-stage manufacturer may petition NHTSA for alternate label locations if none of the above is practical. The location of the label must be easily readable without moving any part of the vehicle except an outer door.

The label must be applied to a clean (free of dirt, wax and grease), dry and smooth surface. For maximum adhesion, the surface temperature should be above 50° Fahrenheit. The labels will adhere to a smooth, curved surface but, it must be clean and dry. The NTEA suggests using a commercially available wax and grease remover on the area before label application.

To apply, peel the backing from one edge (preferably from the top edge) of the label and carefully line up in the designated location. Carefully apply the adhesive side of the label to the surface starting at one edge. Peel the backing from the label while at the same time smoothly applying the label to avoid wrinkles. Use a pin and small squeegee to remove any air bubbles.

If you have any questions or need order additional labels, call the NTEA at 1-800-441-NTEA (6832), or visit the "Storefront" on www.ntea.com. If you have any questions regarding labeling requirements, please contact the NTEA Technical Services Department at 1-800-441-NTEA, or e-mail info@ntea.com.

MFD BY: Brown County
Highway Department

DATE OF MFR: MO. 5 YR. 09

GVWR: 5171 KG (11400 LB)

GAWR-FRONT:
2091 KG (4500 LB)
WITH LT225/75R17E TIRES,
17X6.50 RIMS, @ 420 KPA
(60 PSI) COLD Single

GAWR-INTERMEDIATE(1):
_____ KG (_____ LB)
WITH _____ TIRES,
_____ RIMS, @ _____ KPA
(_____ PSI) COLD _____

GAWR-INTERMEDIATE(2):
_____ KG (_____ LB)
WITH _____ TIRES,
_____ RIMS, @ _____ KPA
(_____ PSI) COLD _____

GAWR-REAR:
3901 KG (8600 LB)
WITH LT225/75R17E TIRES,
17X6.50 RIMS, @ 450 KPA
(65 PSI) COLD Dual

THIS VEHICLE HAS BEEN COMPLETED IN ACCORDANCE WITH THE PRIOR MANUFACTURERS' IVD, WHERE APPLICABLE. THIS VEHICLE CONFORMS TO ALL APPLICABLE FEDERAL MOTOR VEHICLE SAFETY STANDARDS, [AND BUMPER AND THEFT PREVENTION STANDARDS, IF APPLICABLE] IN EFFECT IN:
MO. May YR. 2009

VEHICLE IDENTIFICATION NUMBER:
16BJC74629F148880

VEHICLE TYPE:
Truck

unit # 554

Instructions for Preprinted Yellow Simplified Final-stage Certification Labels

The labels (with the exception of trailer labels) must be placed next to the driver's side of the vehicle at the following locations:

- (a) Hinge pillar,
- (b) Door latch post, or
- (c) Door edge that meets the door latch post.

If none of these positions is available, the label can be placed on either the:

- (a) inward-facing surface of the driver's door, or
- (b) left side of instrument panel.

The final-stage manufacturer may petition NHTSA for alternate label locations if none of the above is practical. The location of the label must be easily readable without moving any part of the vehicle except an outer door.

The label must be applied to a clean (free of dirt, wax and grease), dry and smooth surface. For maximum adhesion, the surface temperature should be above 50° Fahrenheit. The labels will adhere to a smooth, curved surface but, it must be clean and dry. The NTEA suggests using a commercially available wax and grease remover on the area before label application.

To apply, peel the backing from one edge (preferably from the top edge) of the label and carefully line up in the designated location. Carefully apply the adhesive side of the label to the surface starting at one edge. Peel the backing from the label while at the same time smoothly applying the label to avoid wrinkles. Use a pin and small squeegee to remove any air bubbles.

If you have any questions or need order additional labels, call the NTEA at 1-800-441-NTEA (6832), or visit the "Storefront" on www.ntea.com. If you have any questions regarding labeling requirements, please contact the NTEA Technical Services Department at 1-800-441-NTEA, or e-mail info@ntea.com.

MFD BY: Brown County
Highway Department

DATE OF MFR: MO. 5 YR. 09

GVWR: 5171 KG (11400 LB)

GAWR-FRONT:

2041 KG (4500 LB)

WITH LT225/75R17E TIRES,

17X6.5J RIMS, @ 420 KPA

(60 PSI) COLD Single

GAWR-INTERMEDIATE(1):

_____ KG (_____ LB)

WITH _____ TIRES,

_____ RIMS, @ _____ KPA

(_____ PSI) COLD _____

GAWR-INTERMEDIATE(2):

_____ KG (_____ LB)

WITH _____ TIRES,

_____ RIMS, @ _____ KPA

(_____ PSI) COLD _____

GAWR-REAR:

3901 KG (8600 LB)

WITH LT225/75R17E TIRES,

17X6.5J RIMS, @ 450 KPA

(65 PSI) COLD Dual

THIS VEHICLE HAS BEEN COMPLETED IN ACCORDANCE WITH THE PRIOR MANUFACTURERS' IVD, WHERE APPLICABLE. THIS VEHICLE CONFORMS TO ALL APPLICABLE FEDERAL MOTOR VEHICLE SAFETY STANDARDS, [AND BUMPER AND THEFT PREVENTION STANDARDS, IF APPLICABLE] IN EFFECT IN:

MO. May YR. 2009

VEHICLE IDENTIFICATION NUMBER:

1GBJC74609F148876

VEHICLE TYPE:

Truck

unit # 553

Instructions for Preprinted Yellow Simplified Final-stage Certification Labels

The labels (with the exception of trailer labels) must be placed next to the driver's side of the vehicle at the following locations:

- (a) Hinge pillar,
- (b) Door latch post, or
- (c) Door edge that meets the door latch post.

If none of these positions is available, the label can be placed on either the:

- (a) inward-facing surface of the driver's door, or
- (b) left side of instrument panel.

The final-stage manufacturer may petition NHTSA for alternate label locations if none of the above is practical. The location of the label must be easily readable without moving any part of the vehicle except an outer door.

The label must be applied to a clean (free of dirt, wax and grease), dry and smooth surface. For maximum adhesion, the surface temperature should be above 50° Fahrenheit. The labels will adhere to a smooth, curved surface but, it must be clean and dry. The NTEA suggests using a commercially available wax and grease remover on the area before label application.

To apply, peel the backing from one edge (preferably from the top edge) of the label and carefully line up in the designated location. Carefully apply the adhesive side of the label to the surface starting at one edge. Peel the backing from the label while at the same time smoothly applying the label to avoid wrinkles. Use a pin and small squeegee to remove any air bubbles.

If you have any questions or need order additional labels, call the NTEA at 1-800-441-NTEA (6832), or visit the "Storefront" on www.ntea.com. If you have any questions regarding labeling requirements, please contact the NTEA Technical Services Department at 1-800-441-NTEA, or e-mail info@ntea.com.

MFD BY: Brown County
Highway Department

DATE OF MFR: MO. 5 YR. 09

GVWR: 5171 KG (11400 LB)

GAWR-FRONT:
2041 KG (4500 LB)

WITH LT225/75R17E TIRES,
17X6.5J RIMS, @ 420 KPA
(60 PSI) COLD Single

GAWR-INTERMEDIATE(1):
_____ KG (_____ LB)

WITH _____ TIRES,
_____ RIMS, @ _____ KPA
(_____ PSI) COLD _____

GAWR-INTERMEDIATE(2):
_____ KG (_____ LB)

WITH _____ TIRES,
_____ RIMS, @ _____ KPA
(_____ PSI) COLD _____

GAWR-REAR:
3901 KG (8600 LB)

WITH LT225/75R17E TIRES,
17X6.5J RIMS, @ 450 KPA
(65 PSI) COLD Dual

THIS VEHICLE HAS BEEN COMPLETED IN ACCORDANCE WITH THE PRIOR MANUFACTURERS' IVD, WHERE APPLICABLE. THIS VEHICLE CONFORMS TO ALL APPLICABLE FEDERAL MOTOR VEHICLE SAFETY STANDARDS, [AND BUMPER AND THEFT PREVENTION STANDARDS, IF APPLICABLE] IN EFFECT IN:
MO. May YR. 2009

VEHICLE IDENTIFICATION NUMBER:
1GBJC74689F149855

VEHICLE TYPE:
Truck

unit # 552

HIGHWAY DEPARTMENT

Brown County

2198 GLENDALE AVENUE
GREEN BAY, WISCONSIN 54303

CERTIFIED MAIL



7001 1140 0003 5485 5686

RETURN RECEIPT
REQUESTED

W40-304

ADMINISTRATOR
NATIONAL HWY TRAFFIC SAFETY ADMIN
400 7TH STREET SW
WASHINGTON DC 20590



SECURITY OPERATIONS

AUG 31 2009

X-RAYED

