

**TOYOTA PRIUS**  
**VEHICLE IDENTIFICATION NUMBER CODING SYSTEM**

January 2009

Constitution

\*: Described in each section below

Section	1			2				3	4										
	*			*				Check Digit	Model Year	*	Serial Number								
Digit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17		

Section 1: Geographic Area & Country, Manufacturer, and Type of Vehicle

1st - 3rd Digits	Code	Geographic Area & Country	Manufacturer	Type
	JTD	Asia, Japan	Toyota Motor Corporation	Passenger Car

Section 2: Vehicle Description Section

		Code	Description
4th Digit	Body Type	K	5Door Sedan Two-Wheel Drive
5th Digit	Engine Type	N	2ZR-FXE+3JM
6th Digit	Restraint Devices & their Locations	3	Seat Belt: All seats Frontal Air Bag: Driver & Passenger seats Curtain Shield Air Bag: All Rows Side Air Bag: 1 <sup>st</sup> Row Knee Air Bag: Driver seat only
7th Digit	Series	D	ZVW30L
8th Digit	Line & Make	U	TOYOTA PRIUS

Section 4: Vehicle Plant of Manufacture

		Code	Description
11th Digit	Plant of Manufacture	0-2	Tsutsumi Plant, Toyota Motor Corp.
		4-6	Fujimatsu Plant, Toyota Auto Body Corp., LTD