

Constitution

\*: Described in each section below

Section	1			2				3	4									
	*			*				Check Digit	Model Year	*	Serial Number							
Digit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	

Section 1: Geographic Area & Country, Manufacturer, and Type of Vehicle

1st - 3rd Digits	Code	Geographic Area & Country	Manufacturer	Type
	JTH	Asia, Japan	Toyota Motor Corporation	Passenger Car

Section 2: Vehicle Description Section

		Code	Description
4th Digit	Body Type	B	4Door Sedan, Two-Wheel Drive
		C	4Door Sedan, Four-Wheel Drive
5th Digit	Engine Type	L	1UR-FSE
		E	2GR-FSE
		C	2GR-FSE,1KM
6th Digit	Restraint Devices & their Locations	5	Seat Belt: All seats Frontal Air Bag: Driver & Passenger seats Side Air Bag: 1 <sup>st</sup> Row Curtain Shield Air Bag: All Rows Knee Air Bag: Driver & Passenger seats
		1	Seat Belt: All seats Frontal Air Bag: Driver & Passenger seats Side Air Bag: All Rows Curtain Shield Air Bag: All Rows Knee Air Bag: Driver & Passenger seats
7th Digit	Series	K	URS190L GRS191L GRS196L GWS191L
8th Digit	Line & Make	S	LEXUS GS 350 LEXUS GS 460 LEXUS GS 450h

Section 4: Vehicle Plant of Manufacture

		Code	Description
11th Digit	Plant of Manufacture	0-9 *1	Tahara Plant, Toyota Motor Corp.
		5 *2	

\*1 VDS BE5KS, BE1KS, CE5KS and CE1KS \*2 VDS BL5KS, BL1KS, BC5KS and BC1KS