

Constitution

\*: Described in each section below

Section	1			2				3	4										
	*			*				Check Digit	Model Year	*	Serial Number								
Digit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17		

Section 1: Geographic Area & Country, Manufacturer, and Type of Vehicle

1st - 3rd Digits	Code	Geographic Area & Country	Manufacturer	Type
	JTH	Asia, Japan	Toyota Motor Corporation	Passenger Car

Section 2: Vehicle Description Section

		Code	Description
4th Digit	Body Type	B	4Door Sedan, Short Wheel Base, Two-Wheel Drive
		G	4Door Sedan, Long Wheel Base, Two-Wheel Drive
		C	4Door Sedan, Short Wheel Base, Four-Wheel Drive
		D	4Door Sedan, Long Wheel Base, Four-Wheel Drive
5th Digit	Engine Type	L	1UR-FSE
6th Digit	Restraint Devices & their Locations	5	Seat Belt: All seats Frontal Air Bag: Driver & Passenger seats Side Air Bag: 1 <sup>st</sup> Row Curtain Shield Air Bag: All Rows Knee Air Bag: Driver & Passenger seats
		1	Seat Belt: All seats Frontal Air Bag: Driver & Passenger seats Side Air Bag: All Rows Curtain Shield Air Bag: All Rows Knee Air Bag: Driver & Passenger seats
7th Digit	Series	E	USF40L USF41L USF45L USF46L
8th Digit	Line & Make	F	LEXUS LS 460 LEXUS LS 460 L

Section 4: Vehicle Plant of Manufacture

		Code	Description
11th Digit	Plant of Manufacture	5	Tahara Plant, Toyota Motor Corp.