

2006  
ES, GS, IS, LS, SC

## Owner's Manual Supplement

- Owner Amenities
- Warranty Information
- Maintenance Requirements



## **AUTHORIZED DEALERSHIP MAINTENANCE AND REPAIRS**

Lexus recommends having maintenance and repairs for your vehicle performed by an authorized Lexus dealership. To locate your nearest authorized Lexus dealership, contact Lexus Customer Satisfaction at (800) 255-3987 or log on to [www.lexus.com](http://www.lexus.com).

## **IMPORTANT BRAKE INFORMATION: IS 250, IS 350, GS 430**

The 2006 IS 250, IS 350 and GS 430 feature high-friction front brake pads. These pads provide a higher coefficient of friction on the rotors for superior stopping performance and pedal feel. The brakes on these models are designed for high-performance driving. Depending on your driving habits, you may experience more aggressive wear of the brake pads and rotors.

The 2006 GS 430 features an advanced, electronically controlled brake-by-wire system. Lexus wants to make sure that you are aware of this all-new technology and that you become accustomed to its unique sensitivity. For example, you might notice what seems like a very slight delay in vehicle movement when releasing the brake pedal. This might be a little more noticeable after an aggressive stop.

For information on proper maintenance of your brakes, refer to the “Maintenance” section of this booklet. For additional information on your brakes and their operation, refer to your *Owner’s Manual*.

## WELCOME TO THE LEXUS FAMILY

From everyone at Lexus, thank you for purchasing one of our vehicles. Your Lexus is designed to deliver uncompromising luxury and performance. We are committed to providing you with an ownership experience that is second to none, and we look forward to serving you in the years ahead. Welcome to the Lexus family!

### **Taking Delivery of Your New Lexus**

As you take delivery of your new vehicle, there are some important services you should know about. These include:

**Lexus Personalized Settings:** Your vehicle includes a variety of electronic features that can be personalized to your preferences. For example, doors can be programmed to remain locked when you shift into "Park." See your dealer for details.

**Pre-Delivery Service:** Your dealership has performed a thorough service to prepare your vehicle for delivery. This includes initializing certain electronic features, such as the one-touch power windows.

**Scheduled Maintenance:** Your vehicle requires maintenance every six months or 5,000 miles, whichever comes first. The first service is provided at no charge by your dealership. See page 42 for details.

**Dealership Service Department:** Your service department is committed to helping you keep your Lexus performing at its best. Your dealer will provide you with the department's hours of operation, appointment procedures and information on any special services.

**Warranty Coverage:** Your Lexus is covered by one of the finest warranties in the industry. See page 15 for a summary of coverages.

**Roadside Assistance:** Roadside assistance is provided for 48 months from your vehicle's in-service date, regardless of mileage. See page 5 for details.

Again, thank you for choosing Lexus. We wish you many years of safe and pleasurable driving.

## TABLE OF CONTENTS

---

### OWNER AMENITIES

#### Complimentary Services

Lexus Personalized Settings .....	4
First Scheduled Maintenance Service.....	4
Loaner Vehicle.....	4
Travel Protection.....	5
Roadside Assistance .....	5

#### Other Benefits and Assistance

Quality Control .....	7
Vehicle Service History .....	7
Vehicle Service Agreements .....	7
Additional Keys.....	8
Body Repairs.....	8

### WARRANTY INFORMATION

#### Introduction

If You Need Assistance .....	9
The Lexus Commitment .....	14
Warranty Coverages at a Glance.....	15

#### Your Warranties in Detail

General Warranty Provisions .....	16
-----------------------------------	----



## TABLE OF CONTENTS

New Vehicle Limited Warranty .....	18
Federal Emission Control Warranty .....	22
California Emission Control Warranty .....	28
Tire Limited Warranty.....	34

### **Your Responsibilities**

Operation and Maintenance .....	35
Obtaining Warranty Service .....	37

### **MAINTENANCE INFORMATION**

#### **Introduction**

The Importance of Scheduled Maintenance .....	38
Maintenance and Lexus Warranty Coverage.....	39
Lexus Dealership Service .....	40

#### **Scheduled Maintenance Log**

General Maintenance.....	41
Determining Your Maintenance Interval: Months vs. Mileage .....	42
Complimentary First Scheduled Maintenance Service.....	42
Complimentary Lexus Personalized Settings .....	43
Scheduled Maintenance Log .....	44
Explanation of Maintenance Items .....	64
Vehicle Identification.....	69

## COMPLIMENTARY SERVICES

To help ensure that your ownership experience is pleasant, convenient and trouble-free, Lexus provides you with a variety of complimentary services. These services are described on the following pages. Other valuable owner benefits are described in the section entitled “Other Benefits and Assistance” beginning on page 7.

**Lexus Personalized Settings**

Your vehicle includes a variety of electronic features that can be personalized to your preferences. For example, doors can be programmed to remain locked when you shift into “Park.” Programming of these preferences is performed once at no charge, provided you obtain the service at the time of delivery or within 12 months of the vehicle’s in-service date. Programming of your Lexus Personalized Settings requires special equipment and may be performed only by an authorized Lexus dealership.



To obtain your Lexus Personalized Settings, please contact your Lexus dealership. The dealership may verify performance of the service on page 43 of this booklet.

**First Scheduled Maintenance Service**

Lexus also provides your first scheduled maintenance service at no charge. The service is performed at six months or 5,000 miles, whichever occurs first, and includes the service items listed on page 44 of this booklet. To obtain this complimentary scheduled maintenance service, contact your Lexus dealership.

**Loaner Vehicle**

If your vehicle must be kept overnight at a Lexus dealership for a warranty-covered condition that requires more than eight hours to repair, Lexus will provide you with a complimentary loaner vehicle for up to five days.

**Travel Protection**

Lexus will reimburse for a rental car for up to five days and for overnight lodging for up to three nights (not to exceed \$200 per night) if all of the following occur:

- Your vehicle becomes inoperable or unsafe to drive when you are more than 100 miles from home.
- Your vehicle's malfunction is caused by a warranty-covered condition.
- Repairs will take longer than eight hours to complete.

To obtain reimbursement for rental car and lodging expenses, contact a Lexus dealership service consultant.

**Roadside Assistance**

Lexus roadside assistance coverage is for 48 months from your vehicle's in-service date, regardless of mileage. Coverage is provided 24 hours a day, 365 days a year, for vehicles operated in the United States,

U.S. territories and Canada. Assistance is administered through the American Automobile Association.

**Services Provided**

- Roadside services such as battery jump-start, tire change and fuel delivery.
- Towing to the nearest Lexus dealership (or an alternate repair facility, if necessary).
- Assistance in locating alternate transportation and lodging.

**How to Get Help**

To obtain roadside assistance, take the following steps:

- 1) Call (800) 25-LEXUS (800/255-3987).
- 2) Have as much of the following information as possible:
  - Vehicle identification number (located on the driver's side corner of the dashboard, under the window)
  - Owner's name and home address

## COMPLIMENTARY SERVICES

- Vehicle license plate number
  - Location of vehicle, including the nearest major intersection
- 3) To determine your location, the dispatch operator will ask you for the area code and first three digits of the phone number from which you are calling. If you are calling from your cellular phone:
- Obtain a phone number from a telephone near your location; or
  - Call directory assistance and obtain the phone number of a nearby business; or
  - Call the local cellular operator and ask for the area code and prefix of the cell you are in.
- If you are unable to obtain the area code and prefix for the area you are calling from, give the name of the city you are calling from.
- 4) Wait at your vehicle or in a nearby secure location for the roadside assistance provider to arrive.

**Additional Coverage**

After your roadside assistance coverage expires, you may join a motor club created exclusively for Lexus owners. Benefits include roadside assistance coverage, a trip-planning service and discounts on travel and dining. For further information, call (800) 25-LEXUS.

**Quality Control**

You may have noticed a few miles on the odometer when you took delivery of your Lexus. This mileage is a result of the comprehensive process used to ensure the quality of your vehicle. This process includes extensive inspections during and after production. The final inspection takes place at the selling dealership and includes a road-test conducted by a trained Lexus technician.

If you'd like to know more about Lexus quality-control procedures, ask a Lexus dealership service consultant.

**Vehicle Service History**

When you have your vehicle serviced at a Lexus dealership, your service information is recorded in the Lexus National Service History database. This is the first database of its kind in the automotive industry.

It can be accessed by any Lexus dealership in the United States — a great convenience if you relocate or need to have your vehicle serviced while traveling.

**Vehicle Service Agreements**

If you plan to keep your vehicle for several years or if you accumulate mileage quickly, you may want to purchase a Lexus vehicle service agreement. These agreements cover the cost of specific repairs beyond the factory warranty period. They also cover services such as towing, substitute transportation and lodging to minimize your inconvenience should your vehicle require repair. Lexus vehicle service agreements are available with a variety of coverage options. A Lexus dealership sales consultant can help you select the plan that's best for you.

---

**OTHER BENEFITS AND ASSISTANCE**

---

**Additional Keys**

If you require additional keys, call or visit an authorized Lexus dealership. You will need to provide the dealership with your vehicle's key code (found on the key number plate provided with your original set of keys). In most cases, new keys can be ready within five business days.

**Body Repairs**

If you're involved in a collision, you want your vehicle to be returned to its pre-accident condition when repaired. That's why it is important to make sure repairs are made only with Genuine Lexus Parts. Some repair shops and insurance companies may suggest using imitation or salvaged parts to save money. However, these parts do not meet Lexus' high standards for quality, fit and corrosion resistance. In addition, imitation and salvaged parts (and any damage or failures they may cause) are not covered by any Lexus warranty.

The best way to ensure that your vehicle is repaired with Genuine Lexus Parts is to take it to a Lexus dealership. Each dealership works with selected collision repair centers that meet Lexus' strict requirements for training, equipment, quality and customer satisfaction. These repair centers use Genuine Lexus Parts exclusively in the repair of Lexus vehicles.

## IF YOU NEED ASSISTANCE

Both Lexus and your Lexus dealer are dedicated to serving your automotive needs. Your complete satisfaction is our first priority. Should you have a problem or concern, please take the following steps to ensure the quickest possible response:

### Step 1

Discuss the situation with a dealership manager, such as the service manager or customer satisfaction manager. If necessary, ask the dealership owner or general manager for assistance. In most cases, a satisfactory solution can be reached at this step.

### Step 2

If the dealership does not address your concern to your satisfaction, call the Lexus Customer Satisfaction Department at (800) 25-LEXUS (800/255-3987). In Canada, call (800) 26-LEXUS (800/265-3987). In Mexico, call 95-1-310-328-2075. If you are hearing- or speech-impaired, call (800) 443-4999 (TDD).

You may also write to us at:

Lexus Customer Satisfaction Department  
P.O. Box 2991  
Torrance, CA 90509-2991

Whether calling or writing, please provide the following information:

- Vehicle identification number (located on the driver's side corner of the dashboard, under the window)
- Current vehicle mileage
- Name of your selling and servicing Lexus dealerships
- Your day and evening telephone numbers

## IF YOU NEED ASSISTANCE

**Step 3**

If your concern has still not been resolved to your satisfaction, Lexus offers additional assistance through:

**National Center for Dispute Settlement (NCDS)**  
**P.O. Box 561109**  
**Dallas, TX 75356-1109**  
**(866) 272-4872**

**Important:** You must use NCDS prior to exercising rights or seeking remedies available to you through a court action pursuant to the Magnuson-Moss Warranty Act. In addition, you must use NCDS if you are required to do so prior to exercising certain rights or seeking certain remedies available under the Lemon Laws of your state. See the *Owner's Manual Supplement — Lemon Law Information* booklet for specific requirements applicable in your state.

However, if your state law permits and if you choose to exercise rights and seek remedies that are not created by the Act, you need not use NCDS.

**NCDS Arbitration****What is the Dispute Settlement Program?**

This program consists of local NCDS professionals who are trained and experienced in mediation and arbitration. NCDS will arbitrate your case by reviewing the facts; inspecting the vehicle, if necessary; and promptly rendering a fair and equitable decision.

**How much will it cost?**

The service is provided at no cost to you. It is part of Lexus' effort to promptly and equitably resolve your concerns. The decision-maker is an impartial third party. The decision of NCDS is binding on Lexus but not on you.



**What types of disputes are eligible?**

NCDS resolves disputes involving Lexus product reliability and warranty performance that arise during the greater of 1) four years or 50,000 miles from the vehicle's in-service date, whichever is earlier; or 2) the applicable provision of the Lexus New Vehicle Limited Warranty. However, NCDS will not arbitrate 1) claims involving a vehicle used primarily for commercial purposes unless the Lemon Laws of your state cover vehicles used for commercial purposes; or 2) claims that an air bag failed to deploy or deployed when it should not have. Please contact NCDS for further information on eligibility guidelines. You must file a request for arbitration with NCDS within six months of the expiration of the eligibility period, provided the concern or alleged defect was brought to the attention of Lexus or one of its dealers during the eligibility period.

**How long is the arbitration process?**

The entire process — from the time NCDS receives your request for arbitration to the arbitrator's decision — is designed to take no more than 40 days. A decision may be delayed if:

- You fail to provide certain information required by NCDS.
- You fail to make your vehicle available for inspection by NCDS in a timely manner (if an inspection is necessary).

**How do I request arbitration?**

To initiate arbitration, you must complete an NCDS customer claim form and mail it to NCDS. A claim form is included in the *Owner's Manual Supplement — Lemon Law Information* booklet located in your glove box, or you may request a form by calling NCDS at (866) 272-4872. When you call, please have ready your vehicle identification number (VIN), the names of your selling and servicing dealerships, and the current mileage on your Lexus.

---

**IF YOU NEED ASSISTANCE**

---

In addition to completing the customer claim form, please provide NCDS with the following information:

- Vehicle year, make, model, VIN, mileage and date of purchase.
- A brief description of your complaint and the actions you have taken to resolve it.
- What action or remedy you believe would resolve your problem.

If you are seeking reimbursement for repairs or incidental expenses, please provide copies of applicable receipts.

Send your request to:

National Center for Dispute Settlement  
P.O. Box 561109  
Dallas, TX 75356-1109

Upon receipt of your request, NCDS will contact you regarding the status of your case and supply you with additional details about the program.

**How does the arbitration process work?**

When NCDS receives your request, it will be forwarded to the Lexus area office for response.

After analyzing all information pertaining to your case, NCDS will schedule a technical evaluation if applicable. This may include an inspection of the vehicle by a technical expert with a Lexus representative present. The technical expert will forward his or her evaluation to NCDS.

An oral hearing will be held prior to a decision being rendered. At this hearing, all evidence is admissible. You and a Lexus representative will present both sides of the case to the NCDS arbitrator(s). You will each be allotted time to give testimony and provide documents. Then you will each be given an opportunity for rebuttal. After considering all testimony and documents, the arbitrator(s) will review the applicable legal standards and render a decision within 10 days.

A settlement satisfactory to all parties may be negotiated prior to submission of the case to the arbitrator(s), or during the hearing.

**What types of decisions are rendered, and how do I know if Lexus will abide by the decision of NCDS?**

NCDS decisions are based on what NCDS believes to be fair and equitable after applying the appropriate legal standards. Remedies include but are not limited to repairs; reimbursement for repairs and incidental expenses, such as towing costs; and repurchase or replacement of your vehicle.

The decision of NCDS is binding on Lexus but not on you. Lexus must comply with the decision shortly after it is rendered, usually within 30 days of your acceptance of the decision. NCDS will contact you within 10 days of scheduled compliance to ensure that Lexus has complied in a timely manner.

**Are there limits to the scope of NCDS decisions?**

NCDS decisions do not include:

- Attorney fees
- Punitive damages

- Multiple damages
- Consequential damages, other than incidental damages that you may be entitled to under law

**What other recourse do I have?**

If you are dissatisfied with the arbitrator's decision or Lexus' compliance, you may pursue any other legal remedies available to you, including small claims court. You should be aware that NCDS findings are admissible as evidence in any legal proceedings concerning your vehicle.

**Is the Dispute Settlement Program subject to change?**

The information in this booklet about the program is correct as of the date of printing. However, the program may be changed without notice. Contact the Lexus Customer Satisfaction Department at (800) 255-3987 for the most current information concerning the Dispute Settlement Program.

## THE LEXUS COMMITMENT

You have purchased one of the finest vehicles built in the world today, and it is backed by one of the finest warranties in the industry. This excellent warranty coverage demonstrates not only our confidence in Lexus vehicles, but also our commitment to every Lexus customer. We're dedicated to ensuring that you enjoy exceptional quality, dependability and peace of mind throughout your ownership experience.

To further demonstrate our commitment to our customers' satisfaction, occasionally we may establish a special policy adjustment to pay for specific repairs that are no longer covered by warranty. When we establish such a policy adjustment, we mail details to all applicable owners on record. That's why it is important to send in the card at the back of this booklet if you change your address or if you have purchased your Lexus from a previous owner.

You've made a wise decision to purchase a Lexus. Your vehicle delivers world-class luxury and performance, along with an unparalleled commitment from

Lexus to ensuring your satisfaction. You can be confident — as we are — that you'll enjoy owning your Lexus as much as you enjoy driving it.


This section of the *Owner's Manual Supplement* describes the terms of Lexus warranty coverage as well as general owner responsibilities. The section entitled "Maintenance Information" beginning on page 38 describes your vehicle's maintenance requirements. Be sure to review this information carefully, since proper maintenance is required to ensure that warranty coverage remains intact.

All warranty information is the latest available at the time of publication and, with the exception of the emission control warranties, is subject to change without notice.


## WARRANTY COVERAGES AT A GLANCE

WARRANTY

### New Vehicle Limited Warranty



### Emission Control Warranty



\*Specific components may have longer coverage under terms of the Powertrain Warranty.

†Also applies to Maine, Massachusetts and Vermont vehicles equipped with a California Certified Emission Control System. Vehicles covered by this warranty are also covered by the Federal Emission Control Warranty.

## GENERAL WARRANTY PROVISIONS

**Who Is the Warrantor**

The warrantor for these limited warranties is Lexus, a division of Toyota Motor Sales, U.S.A., Inc., 19001 South Western Avenue, Torrance, California 90509-2991, a California corporation.

**Which Vehicles Are Covered**

These warranties apply to 2006 model-year Lexus passenger vehicles registered and normally operated in the United States, U.S. territories and Canada. Warranty coverage is automatically transferred at no cost to subsequent vehicle owners.

**Multiple Warranty Conditions**

This booklet contains warranty terms and conditions that may vary depending on the part covered. A warranty for specific parts or systems, such as the Powertrain Warranty or Emission Performance Warranty, is governed by the coverage set forth in that warranty as well as the General Warranty Provisions.

**When Warranty Begins**

The warranty period begins on the vehicle's in-service date, which is the first date the vehicle is either delivered to an ultimate purchaser, leased, or used as a company car or demonstrator.

**Repairs Made at No Charge**

Repairs and adjustments covered by these warranties are made at no charge for parts and labor.

**Parts Replacement**

Any needed parts replacement will be made using new or remanufactured parts. The decision whether a part should be repaired or replaced will be made by the servicing Lexus dealership and/or Lexus. Parts scheduled to be replaced as required maintenance are warranted until their first replacement only.

**Note:** Lexus remanufactured parts meet or exceed all factory standards for safety, quality and reliability.

**Limitations**

The performance of necessary repairs and adjustments is the exclusive remedy under these warranties or any implied warranties. Lexus does not authorize any person to create for it any other obligation or liability in connection with this vehicle.

**Any implied warranty of merchantability or fitness for a particular purpose is limited to the duration of these written warranties.** Some states do not allow restrictions on how long an implied warranty lasts, so this limitation may not apply to you.

**Your Rights Under State Law**

These warranties give you specific legal rights. You may also have other rights that vary from state to state.

## NEW VEHICLE LIMITED WARRANTY

## WHAT IS COVERED AND HOW LONG

**Basic Warranty**

This warranty covers repairs and adjustments needed to correct defects in materials or workmanship of any part supplied by Lexus, subject to the exceptions indicated under “What Is Not Covered” on pages 19–20.

Coverage is for 48 months or 50,000 miles, whichever occurs first, with the exception of wheel alignment and wheel balancing, which are covered for 12 months or 20,000 miles, whichever occurs first.

**Powertrain Warranty**

This warranty covers repairs needed to correct defects in materials or workmanship of any component listed here and supplied by Lexus, subject to the exceptions indicated under “What Is Not Covered” on pages 19–20.

Coverage is for 72 months or 70,000 miles, whichever occurs first.

**Engine**

Cylinder block and head and all internal parts, timing belt and cover, flywheel, oil pan, water pump, fuel

pump, engine mounts, engine control computer, seals and gaskets.

**Transmission and Transaxle**

Case and all internal parts, torque converter, clutch cover, mounts, engine control computer, seals and gaskets.

**Front-Wheel-Drive System**

Drive shaft, axle, hub, bearings, seals and gaskets.

**Rear-Wheel-Drive System**

Differential carrier assembly, drive shaft, axle carrier, axle case, axle bearing, axle shaft, seals and gaskets.

**Restraint Systems Warranty**

This warranty covers repairs needed to correct defects in materials or workmanship of any seatbelt or air bag system supplied by Lexus, subject to the exceptions indicated under “What Is Not Covered” on pages 19–20.

Coverage is for 72 months or 70,000 miles, whichever occurs first.



For vehicles sold and registered in Kansas, the warranty for seatbelts and related components is 10 years, regardless of mileage.

#### **Corrosion Perforation Warranty**

This warranty covers repair or replacement of any original body panel that develops perforation from corrosion (rust-through), subject to the exceptions indicated under “What Is Not Covered” on pages 19–20.

Coverage is for 72 months, regardless of mileage.

For information on how to protect your vehicle from corrosion, see the section entitled “Service Procedures and Specifications – Body” in the *Owner's Manual*.

#### **Towing**

When your vehicle is inoperable due to failure of a warranted part, towing service to the nearest authorized Lexus dealership is covered.

#### **WHAT IS NOT COVERED**

This warranty does not cover damage or failures resulting directly or indirectly from any of the following:

- Fire, accidents or theft
- Abuse or negligence
- Misuse — for example, racing or overloading
- Improper repairs
- Alteration or tampering, including installation of non-Genuine Lexus Accessories
- Lack of or improper maintenance, including use of fluids other than those specified in the *Owner's Manual*
- Installation of non-Genuine Lexus Parts
- Airborne chemicals, tree sap, road debris (including stone chips), rail dust, salt, hail, floods, wind storms, lightning and other environmental conditions
- Water contamination

## NEW VEHICLE LIMITED WARRANTY

This warranty also does not cover the following:

**Tires**

Tires are covered by a separate warranty provided by the tire manufacturer. See page 34.

**Normal Wear and Tear**

Noise, vibration, cosmetic conditions and other deterioration caused by normal wear and tear.

**Maintenance Expense\***

Normal maintenance services such as engine tune-ups; replacement of fluids and filters; lubrication; cleaning and polishing; replacement of spark plugs and fuses; and replacement of worn wiper blades, brake pads/linings and clutch linings.

**Vehicles With Altered Odometer**

Failure of a vehicle on which the odometer has been altered so that actual vehicle mileage cannot be readily determined.

**Vehicles With Unknown Vehicle Identification Number**

Any vehicle for which the original factory-assigned vehicle identification number cannot be determined.

**Salvage or Total-Loss Vehicles**

Any vehicle that has ever been issued a "salvage" title or similar title under any state's law; or has ever been declared a "total loss" or equivalent by a financial institution or insurer, such as by payment for a claim in lieu of repairs because the cost of repairs exceeded the cash value of the vehicle. This exclusion does not apply to the emission control warranties.

**Incidental Damages**

Incidental or consequential damages associated with a vehicle failure. Such damages include but are not limited to inconvenience; the cost of transportation, telephone calls and lodging; the loss of personal or commercial property; and the loss of pay or revenue.

\*Lexus provides the first scheduled maintenance service at no charge. See page 4 for details.

**Disclaimer of Extra Expenses and Damages**

The performance of necessary repairs and adjustments is the exclusive remedy under this warranty or any implied warranty. Lexus does not authorize any person to create for it any other obligation or liability in connection with this vehicle. Lexus shall not be liable for incidental or consequential damages resulting from breach of this written warranty or any implied warranty.

Any implied warranty of merchantability or fitness for a particular purpose is limited to the duration of this written warranty, except in states where this limitation is not allowed.

**DISPUTE RESOLUTION**

If a dispute arises regarding your warranty coverage, please follow the steps described on pages 9–10. Please note that you must use the National Center for Dispute Settlement before seeking remedies through a court action pursuant to the Magnuson-Moss Warranty Act. You may also be required to use the National Center for Dispute Settlement before seeking remedies under the Lemon Laws of your state. For the requirements applicable to your state, see the appropriate page of the *Owner's Manual Supplement – Lemon Law Information* booklet located in your glove box.

## FEDERAL EMISSION CONTROL WARRANTY

## WHAT IS COVERED AND HOW LONG

**Emission Defect Warranty**

Lexus warrants that your vehicle:

- Was designed, built and equipped to conform at the time of sale with applicable federal emissions standards.
- Is free from defects in materials and workmanship that may cause the vehicle to fail to meet these standards.

Federal regulations require that this warranty be in effect for two years or 24,000 miles from the vehicle's in-service date, whichever occurs first. However, under the terms of the Basic Warranty, Lexus provides coverage of four years or 50,000 miles, whichever occurs first. Specific components may have longer coverage under the terms of the Powertrain Warranty. Additionally, components marked "8/80" in the parts list on pages 23–24 have coverage of eight years or 80,000 miles, whichever occurs first.

**Emission Performance Warranty**

Some states and localities have established vehicle inspection and maintenance (I/M) programs to encourage proper vehicle maintenance. If an EPA-approved I/M program is in force in your area, you are eligible for Emission Performance Warranty coverage.

Under the terms of the Emission Performance Warranty and federal regulations, Lexus will make all necessary repairs if both of the following occur:

- Your vehicle fails to meet applicable emissions standards as determined by an EPA-approved emissions test.
- This failure results or will result in some penalty to you — such as a fine or denial of the right to use your vehicle — under local, state or federal law.

This warranty is in effect for two years or 24,000 miles from the vehicle's in-service date, whichever occurs first. Additionally, components marked "8/80" in the parts list on pages 23–24 have coverage of eight years or 80,000 miles, whichever occurs first.

**WHAT IS NOT COVERED**

These warranty obligations do not apply to failures or noncompliance caused by:

- The use of replacement parts not certified in accordance with aftermarket parts certification regulations.
- The use of replacement parts not equivalent in quality or design to original equipment parts.

Provisions under the “What Is Not Covered” section of the New Vehicle Limited Warranty also apply to this warranty.

**WARRANTY PARTS LIST**

**Air/Fuel Metering System**

- Air/fuel ratio feedback control system
- Cold-start enrichment system
- Deceleration control system
- Electronic fuel injection system components
  - Airflow sensor
  - Engine control module (8/80)
  - Throttle body
  - Other components

**Air Induction System**

- Intake manifold and intake air surge tank

**Air Injection System**

- Air injection manifold
- Air injection pump
- Airflow control valves

8/80 = Covered for eight years or 80,000 miles, whichever occurs first.

FEDERAL EMISSION CONTROL WARRANTY

---

**Catalyst System**

- Catalytic converter and protector (8/80)
- Constricted fuel filler neck
- Exhaust manifold
- Exhaust pipe (manifold to catalyst and/or catalyst to catalyst)

**Evaporative Control System**

- Charcoal canister
- Diaphragm valve
- Fuel filler cap
- Fuel tank
- Vapor liquid separator

**Exhaust Gas Recirculation (EGR) System**

- EGR gas temperature sensor
- EGR valve
- Associated parts

**Ignition System**

- Distributor and internal parts
- Ignition coil and ignitor
- Ignition wires
- Spark plugs\*

**Positive Crankcase Ventilation (PCV) System**

- Oil filler cap
- PCV valve or orifice

**Other Parts Used in Above Systems**

- Data link connector (8/80)
- Hoses, clamps, fittings, tubing and mounting hardware
- Malfunction indicator light and bulb (8/80)
- Pulleys, belts and idlers
- Sealing gaskets and devices
- Sensors, solenoids, switches and valves

---

8/80 = Covered for eight years or 80,000 miles, whichever occurs first.

\*Warranted until first required maintenance under terms of the California Emission Control Warranty.

### MAINTENANCE

You are responsible for performance of the required maintenance indicated in the *Owner's Manual* and this supplement. Lexus will not deny a warranty claim solely because you do not have records to show that you maintained your vehicle. However, any failure or noncompliance caused by lack of maintenance is not covered by this warranty.

**When maintenance and repairs are paid for by you, these services may be performed by you or by any automotive service provider you choose. Lexus will not deny a warranty claim solely because you used a service provider other than a Lexus dealership for maintenance and repairs.** However, any failure or noncompliance caused by improper maintenance or repairs is not covered by this warranty.

### REPLACEMENT PARTS

To ensure optimum performance and maintain the quality built into your vehicle's emission control systems, Lexus recommends the use of Genuine Lexus Parts when servicing or repairing the systems.

**Warranty coverage is not dependent upon the use of any particular brand of replacement parts and you may elect to use non-Genuine Lexus Parts for maintenance and repairs. However, use of replacement parts that are not equivalent in quality to Genuine Lexus Parts may impair the effectiveness of the emission control systems.**

If you use replacement parts that have maintenance or replacement schedules different from those of Genuine Lexus Parts, you must follow the maintenance and replacement schedules for the parts you are using. In addition, you should ensure that such parts are warranted by their manufacturers to be equivalent to Genuine Lexus Parts.

## FEDERAL EMISSION CONTROL WARRANTY

**IF YOUR VEHICLE FAILS AN EMISSIONS TEST**

If your vehicle fails an EPA-approved emissions test, you may make a claim under the Emission Performance Warranty. To do so, take your vehicle to an authorized Lexus dealership and present a copy of the emissions test report. Also, take your maintenance records in case they are needed.

If your claim qualifies for coverage, the dealership will repair your vehicle within 30 days (unless a shorter period is required by law). If your claim is denied, Lexus will notify you in writing of the reason within the same period. If we fail to do so, we will repair your vehicle free of charge. The only exceptions allowed are when you request or agree to a delay, or when a delay is caused by factors beyond the control of Lexus or the dealership.

For information on how to obtain service under the Emission Defect Warranty, see page 37, "Obtaining Warranty Service."

**IF YOU HAVE QUESTIONS**

If you have questions or concerns about your vehicle's federal emission warranty coverage, please follow the steps described on pages 9–10. In the case of the Emission Performance Warranty, you may also request information from or report complaints to:

U.S. Environmental Protection Agency  
Vehicle Programs & Compliance Division (6405J)  
Attn: Warranty Complaints  
401 M Street SW  
Washington, D.C. 20460

Vehicles equipped with a California Certified Emission Control System that are registered and operated in California or any state that adopts California emission warranty provisions are also covered by the California Emission Control Warranty (see page 28). Maine, Massachusetts and Vermont are the only other states to which the California Emission Control Warranty currently applies.



## FEDERAL EMISSION CONTROL WARRANTY

WARRANTY

### DEALER CERTIFICATE

We (the dealership) want you to know that at the time your new Lexus vehicle is being delivered:

- 1) On the basis of written notification furnished by Lexus, we have knowledge that the vehicle is covered by an EPA Certificate of Conformity.
- 2) We have visually inspected those emission control devices or portions thereof that are visible without removing or adjusting any components or systems, emissions-related or otherwise. On the basis of this inspection, there are no apparent deficiencies in the installation of emission control devices by Lexus. (For purposes of this certificate, "emission control devices" is limited to devices installed on a vehicle for the sole or primary purpose of controlling emissions and which were not in general use before 1968.)
- 3) We have performed all emission control system preparations required by Lexus prior to the sale of the vehicle as set forth in Lexus' current pre-delivery service manual.
- 4) Except as may be provided in Paragraph 5, if this vehicle fails an EPA-approved emissions test within three months or 4,000 miles (whichever comes first) of delivery to the ultimate purchaser, and the vehicle

has been maintained and used in accordance with the written instructions for proper maintenance and use, Lexus will remedy the nonconformity free of charge under the terms of the Emission Performance Warranty.

- 5) If vehicle was used as a company car or demonstrator, check box and complete the following:

The vehicle with which this statement is delivered was placed into service as a company car or demonstrator prior to delivery. The Emission Performance Warranty period commenced on the date the vehicle was first placed into service, which was \_\_\_\_\_  
Month Day Year

**Note:** The dealership makes no representation or warranty that the emission control system or any part thereof is without defect or that the system will perform properly. The Emission Performance Warranty referred to in Paragraph 4 and furnished with the vehicle is solely that of the manufacturer. This statement is required by section 207 of the Clean Air Act (42 U.S.C. 7541) and the EPA regulations issued thereunder.

\_\_\_\_\_  
Dealership name

*Your Warranties in Detail*

## CALIFORNIA EMISSION CONTROL WARRANTY

## YOUR WARRANTY RIGHTS AND OBLIGATIONS

The California Air Resources Board (CARB) and Lexus are pleased to explain the emission control system warranty for your 2006 vehicle. In California, new motor vehicles must be designed, built and equipped to meet the state's stringent anti-smog standards. CARB regulations require that Lexus must warrant the emission control system on your vehicle for the time periods indicated on this page, provided there has been no abuse, neglect or improper maintenance of your vehicle.

Your emission control system may include parts such as the fuel injection system, ignition system, catalytic converter and engine computer. Also included may be hoses, belts, connectors and other emissions-related assemblies.

Where a warrantable condition exists, Lexus will repair your vehicle at no cost to you, including diagnosis, parts and labor.

## MANUFACTURER'S WARRANTY COVERAGE

- 1) For three years or 50,000 miles, whichever occurs first:
  - If your vehicle fails a smog-check test, all necessary repairs and adjustments will be made by Lexus to ensure that your vehicle passes the test. This is your Emission Control System PERFORMANCE WARRANTY.
  - If any emissions-related part on your vehicle is defective, the part will be repaired or replaced by Lexus. This is your SHORT-TERM Emission Control System DEFECT WARRANTY. Covered parts are listed on pages 23–24.
 

**Note:** Under the terms of the Basic Warranty, Lexus provides coverage of four years or 50,000 miles, whichever occurs first. Specific components may have longer coverage under the terms of the Powertrain Warranty.
- 2) For seven years or 70,000 miles, whichever occurs first:
  - If an emissions-related part listed on page 30 is defective, the part will be repaired or replaced by Lexus. This is your LONG-TERM Emission Control System DEFECT WARRANTY.

## CALIFORNIA EMISSION CONTROL WARRANTY

W  
A  
R  
R  
A  
N  
T  
Y

### OWNER'S WARRANTY RESPONSIBILITIES

You are responsible for performance of the required maintenance indicated in the *Owner's Manual* and this supplement. Lexus recommends that you retain all receipts covering maintenance on your vehicle, but Lexus cannot deny warranty coverage solely for the lack of receipts or your failure to ensure the performance of all scheduled maintenance.

You are responsible for presenting your vehicle to a Lexus dealership as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

You should also be aware that Lexus may deny you warranty coverage if your vehicle or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

If you have any questions regarding your warranty rights and responsibilities, you should contact the Lexus Customer Satisfaction Department at (800) 255-3987 or the California Air Resources Board, Mobile Source Control Division, at 9528 Telstar Avenue, P.O. Box 8001, El Monte, CA 91734-8001.

### WHAT IS NOT COVERED

These warranty obligations do not apply to failures or noncompliance caused by:

- The use of replacement parts not certified in accordance with aftermarket parts certification regulations.
- The use of replacement parts not equivalent in quality or design to original equipment parts.

Provisions under the "What Is Not Covered" section of the New Vehicle Limited Warranty also apply to this warranty.

## CALIFORNIA EMISSION CONTROL WARRANTY

**PARTS LIST: LONG-TERM EMISSION DEFECT WARRANTY**

The parts listed here are covered for seven years or 70,000 miles from the vehicle's in-service date, whichever occurs first.

**Air/Fuel Metering System**

- Engine control computer (engine control module)
- Fuel pump on IS 250, IS 350, SC 430
- High-pressure fuel pump on GS 300
- Throttle body

**Air Induction System**

- Intake manifold and intake air surge tank

**Catalyst System**

- Catalytic converter (warm-up three-way catalyst)
- Exhaust front pipe
- Exhaust manifold
- Exhaust manifold gasket on GS 430, LS 430, SC 430

**Evaporative Control System**

- Charcoal canister on ES 330, GS 300, GS 430, IS 250, IS 350, SC 430
- Fuel tank

**Ignition System**

- Knock sensor on ES 330, GS 430, IS 250, IS 350, LS 430, SC 430

**Other Parts Used in Above Systems**

- Transmission solenoid on GS 300, GS 430, IS 250, IS 350, SC 430

### MAINTENANCE

You are responsible for performance of the required maintenance indicated in the *Owner's Manual* and this supplement. Lexus will not deny a warranty claim solely because you do not have records to show that you maintained your vehicle. However, any failure or noncompliance caused by lack of maintenance is not covered by this warranty.

**When maintenance and repairs are paid for by you, these services may be performed by you or by any automotive service provider you choose. Lexus will not deny a warranty claim solely because you used a service provider other than a Lexus dealership for maintenance and repairs.** However, any failure or noncompliance caused by improper maintenance or repairs is not covered by this warranty.

### REPLACEMENT PARTS

To ensure optimum performance and maintain the quality built into your vehicle's emission control systems, Lexus recommends the use of Genuine Lexus Parts when servicing or repairing the systems.

**Warranty coverage is not dependent upon the use of any particular brand of replacement parts and you may elect to use non-Genuine Lexus Parts for maintenance and repairs. However, use of replacement parts that are not equivalent in quality to Genuine Lexus Parts may impair the effectiveness of the emission control systems.**

If you use replacement parts that have maintenance or replacement schedules different from those of Genuine Lexus Parts, you must follow the maintenance and replacement schedules for the parts you are using. In addition, you should ensure that such parts are warranted by their manufacturers to be equivalent to Genuine Lexus Parts.

## CALIFORNIA EMISSION CONTROL WARRANTY

**IF YOUR VEHICLE  
FAILS A SMOG-CHECK TEST**

If your vehicle fails a smog-check test, you may make a claim under the Emission Performance Warranty. To do so, take your vehicle to an authorized Lexus dealership and present a copy of the smog-check test report. Also, take your maintenance records in case they are needed.

If your claim qualifies for coverage, the dealership will repair your vehicle within 30 days (unless a shorter period is required by law). If your claim is denied, Lexus will notify you in writing of the reason within the same period. If we fail to do so, we will repair your vehicle free of charge. The only exceptions allowed are when you request or agree to a delay, or when a delay is caused by factors beyond the control of Lexus or the dealership.

For information on how to obtain service under the Emission Defect Warranty, see page 37, "Obtaining Warranty Service."

**REPAIR DELAYS**

If a Lexus dealership is unable to complete repairs on your vehicle within 30 days, you may have the repairs made under Lexus' provisions for emergency warranty repairs. See page 37 for details.

**IF YOU HAVE QUESTIONS**

If you have questions or concerns about your vehicle's California emission warranty coverage, please follow the steps described on pages 9–10. You may also request information from or report complaints to:

California Air Resources Board  
Mobile Source Control Division  
P.O. Box 8001  
El Monte, CA 91734-8001  
(800) 242-4450

Vehicles equipped with a California Certified Emission Control System that are registered and operated in California or any state that adopts California emission warranty provisions are covered by this warranty. Maine, Massachusetts and Vermont are the only other states to which this warranty currently applies. Vehicles covered by this warranty are also covered by the Federal Emission Control Warranty (see page 22).

## TIRE LIMITED WARRANTY

**OBTAINING WARRANTY SERVICE**

The tires that come as original equipment on your vehicle are warranted by their manufacturer and not Lexus. Please refer to the tire warranty statement included with the owner information in your vehicle.

To obtain warranty service for a tire, take the tire to an authorized dealer of the tire manufacturer. (Refer to your local phone directory for dealer locations.) Your Lexus dealer may also be able to assist you in obtaining warranty service from the manufacturer.

For additional warranty information or service assistance, contact the tire manufacturer directly.

**ORIGINAL EQUIPMENT TIRE MANUFACTURERS**

**Bridgestone/Firestone**  
535 Marriott Drive  
Nashville, TN 37214  
Bridgestone:  
(800) 847-3272  
Firestone: (800) 356-4644

**Dunlop Tires**  
1144 East Market Street  
Akron, OH 44316  
(800) 321-2136

**Goodyear Tire and Rubber Co.**  
1144 East Market Street  
Akron, OH 44316  
(800) 321-2136

**Michelin North America**  
One Park Way South  
P.O. Box 19001  
Greenville, SC 29602  
(800) 847-3435

**Toyo Tire (U.S.A.) Corporation**  
6261 Katella Avenue,  
Suite 2B  
Cypress, CA 90630  
(800) 442-8696

**Yokohama Tire Corporation**  
601 South Acacia Avenue  
Fullerton, CA 92831  
(800) 722-9888



**GENERAL INFORMATION**

You are responsible for ensuring that your Lexus is operated and maintained according to the instructions in the *Owner's Manual* and the "Maintenance Information" section of this supplement.

You should keep detailed records of vehicle maintenance, since under some circumstances they may be required for warranty coverage. These records should include date of service, mileage at time of service and a description of service performed and/or parts installed. For your convenience, maintenance logs are included in the "Maintenance Information" section of this supplement. If you sell your vehicle, you should give your maintenance records to the new owner.

Lexus will not deny a warranty claim solely because you do not have records to show that you maintained your vehicle. However, damage or failures caused by lack of proper maintenance are not covered under warranty.

**WHERE TO GO FOR MAINTENANCE**

You may have maintenance performed on your vehicle by any qualified person or facility. However, Lexus recommends having maintenance performed by an authorized Lexus dealership.

Lexus dealership technicians are specially trained to maintain and repair Lexus vehicles. They stay current on the latest service information through Lexus technical bulletins, service publications and training courses. Many are also certified through the Lexus Commitment to Perfection Certification Program, which requires specialized, state-of-the-art training as well as rigorous exams through both Lexus and the National Institute for Automotive Service Excellence.

You can be confident you're getting the best possible service for your vehicle when you take it to a Lexus dealership. Plus, a Lexus dealership will always use Genuine Lexus Parts designed specifically for your vehicle.

**REPLACEMENT PARTS**

Warranty coverage is not dependent upon the use of any particular brand of replacement parts. However, Lexus recommends using only Genuine Lexus Parts when you need to replace a part on your vehicle. Like all Lexus products, Genuine Lexus Parts are built to the highest standards of quality, durability and performance. They are also designed to fit your vehicle's exact specifications.

Your Lexus dealership maintains an extensive inventory of Genuine Lexus Parts to meet your vehicle service needs. And because it is linked electronically to Lexus Parts Distribution Centers, the dealership has quick access to any parts it may not have in stock.

Genuine Lexus Parts are covered by their own warranty (see your dealer for details) or the remainder of any applicable New Vehicle Limited Warranty, whichever is longer. **Non-Genuine Lexus Parts, or any damage or failures resulting from their use, are not covered by any Lexus warranty.**

BY GEOGRAPHIC REGION

**In the United States, U.S. Territories and Canada**

To obtain warranty service in the United States, U.S. territories or Canada, take your vehicle to an authorized Lexus dealership. If your vehicle cannot be driven, contact your nearest Lexus dealership for towing assistance. You do not have to pay for towing to the nearest Lexus dealership if your vehicle is inoperable due to failure of a warranted part.

**Outside the United States, U.S. Territories and Canada**

If you are using your vehicle outside the United States, U.S. territories and Canada and need warranty service, contact a local Lexus dealership. Please note, however, that your vehicle may not be repaired free of charge because the local Lexus distributor may have no obligation to provide warranty service for your vehicle, and/or your vehicle may not comply with local regulatory or environmental requirements.

EMERGENCY REPAIRS

If your vehicle is inoperable or unsafe to drive and there is no Lexus dealership reasonably available to make repairs, you may perform the repairs yourself or have them performed by another automotive service provider. Lexus will reimburse you for any of the repairs that are covered by warranty. To receive reimbursement, present to an authorized Lexus dealership your paid repair invoices and any parts that were removed from the vehicle. You will be reimbursed for warranted parts at the manufacturer's suggested retail price and warranted labor at a geographically appropriate hourly rate multiplied by Lexus' recommended time allowance for the repair.

If your vehicle requires emergency repair, Lexus assumes no liability for subsequent failures caused by improper repairs or the use of non-Genuine Lexus Parts unless you have the vehicle properly repaired in a timely manner. To ensure that warranty coverage remains intact, have your vehicle inspected by an authorized Lexus dealership as soon as possible after an emergency repair.

## THE IMPORTANCE OF SCHEDULED MAINTENANCE

Regular maintenance is essential to obtaining the highest level of performance, safety and reliability from your Lexus. It can also enhance your vehicle's resale value. This section of the *Owner's Manual Supplement* is designed to help you make sure your vehicle receives proper and timely maintenance. It includes factory-recommended maintenance guidelines as well as logs in which to document your vehicle's maintenance history.

In addition to scheduled maintenance, your Lexus requires ongoing general maintenance such as fluid checks and visual inspections. These procedures are listed on page 41 of this booklet and described in detail in the "Maintenance" section of the *Owner's Manual*.

With proper maintenance and care, your vehicle will last longer and deliver more dependable, economical performance. Follow this booklet's recommendations and you'll enjoy maximum reliability and peace of mind from your Lexus for many years to come.



Maintaining your vehicle according to the recommendations in this booklet is required to ensure that your warranty coverage remains intact. You should keep detailed records of vehicle maintenance, including date of service, mileage at time of service and a description of service and/or parts installation performed. The maintenance logs in this booklet are a good place to record this information. If you sell your vehicle, be sure to give your maintenance records to the new owner.

Lexus will not deny a warranty claim solely because you do not have records to show that you maintained your vehicle. However, damage or failures caused by lack of proper maintenance are not covered under warranty.

Maintenance and repair services may be performed by you or by any automotive service provider you choose. Lexus will not deny a warranty claim solely because you used a service provider other than a Lexus dealership for maintenance and repairs. However, damage

or failures caused by improper maintenance or repairs are not covered under warranty.

Your dealer may recommend more frequent maintenance intervals or more maintenance services than those listed in the scheduled maintenance log. These additional services are not required to maintain your warranty coverage. Ask your dealer for an explanation of any recommended maintenance not included in the scheduled maintenance log.

For a complete description of Lexus warranty coverages, see pages 16–33 of this booklet.

## LEXUS DEALERSHIP SERVICE

To ensure that your vehicle receives first-quality service and factory-authorized parts, Lexus recommends having maintenance performed by an authorized Lexus dealership. To locate your nearest authorized Lexus dealership, contact Lexus Customer Satisfaction at (800)255-3987 or log on to [www.lexus.com](http://www.lexus.com).

Lexus dealership technicians are experts in the maintenance and repair of Lexus vehicles. They stay current on the latest service information through Lexus technical bulletins, service publications and training courses. Many are also certified through the Lexus Commitment to Perfection Certification Program, which requires specialized, state-of-the-art training as well as rigorous exams through both Lexus and the National Institute for Automotive Service Excellence.

Additionally, when you have your vehicle serviced at a Lexus dealership, your service information is recorded in the Lexus National Service History database. This is the first database of its kind in the automotive industry. It can be accessed by any Lexus dealership in

the U.S. — a great convenience if you relocate or need to have your vehicle serviced while traveling.

You can be confident you're getting the best possible service for your vehicle when you take it to a Lexus dealership. Don't trust your investment to anything less than a team of Lexus specialists.

Maintenance and repairs not performed by an authorized Lexus dealership should be performed by a qualified technician following procedures in Lexus service and repair publications.

In addition to scheduled maintenance, your Lexus requires ongoing general maintenance such as fluid checks and visual inspections. The recommended guidelines for inspections are listed below. Please refer to the “Maintenance” section of the *Owner’s Manual* for a detailed description of inspection procedures.

**When Refueling**

When refueling, perform these inspections:

- Check engine oil level using the dipstick
- Visually check engine coolant level on the see-through reservoir
- Visually check brake fluid level on the see-through reservoir
- Visually check condition of battery
- Check level of windshield washer fluid

**Every 30 Days**

At least once every 30 days, perform these inspections:

- Check tire pressure
- Check tires for damage and wear

## SCHEDULED MAINTENANCE LOG

**Determining Your Maintenance Interval:  
Months vs. Mileage**

Lexus recommends obtaining scheduled maintenance for your vehicle every six months or 5,000 miles, whichever occurs first.

For example:

- If at six months you have driven less than 5,000 miles, you should obtain maintenance at **six months**; don't wait until 5,000 miles.
- If you drive 5,000 miles in less than six months, you should obtain maintenance at **5,000 miles**; don't wait until six months.

Be sure to keep an eye on your mileage so that you obtain maintenance when recommended. If you are a low-mileage driver, mark your calendar to remind yourself to obtain maintenance every six months.

**Complimentary First Scheduled Maintenance Service**

Lexus provides your first scheduled maintenance service at no charge. The service is performed at six months or 5,000 miles, whichever occurs first, and includes the service items listed on page 44. To obtain this complimentary scheduled maintenance service, contact your Lexus dealership.



**Complimentary Lexus Personalized Settings**

Your vehicle includes a variety of electronic features that can be personalized to your preferences. For example, doors can be programmed to remain locked when you shift into “Park.” Programming of these preferences is performed once at no charge, provided you obtain the service at the time of delivery or within 12 months of the vehicle’s in-service date. Programming of your Lexus Personalized Settings requires special equipment and may be performed only by an authorized Lexus dealership.



To obtain your Lexus Personalized Settings, please contact your Lexus dealership. The dealership may verify performance of the service in the box on this page.

**Lexus Personalized Settings\***

Must be obtained within 12 months of vehicle’s in-service date.

In-service date: \_\_\_\_\_

Date personalized settings programmed: \_\_\_\_\_

Notes:

\*This service is complimentary when performed by an authorized Lexus dealership.

SCHEDULED MAINTENANCE LOG

**6 Months or 5,000 Miles\***

- Replace engine oil and oil filter<sup>1</sup>
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>
  - Axle shaft boots
  - Ball joints and dust covers
  - Engine air filter
  - Nuts and bolts on chassis
  - Steering linkage and boots

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

**12 Months or 10,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Measure thickness of front brake pads and rotors (GS 430, IS)
- Replace air conditioner filter (GS 300, GS 430, IS 350, LS 430, SC)
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>
  - Axle shaft boots
  - Ball joints and dust covers
  - Engine air filter
  - Nuts and bolts on chassis
  - Steering linkage and boots

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

\*This service is complimentary when performed by an authorized Lexus dealership.

## SCHEDULED MAINTENANCE LOG

### 18 Months or 15,000 Miles

- Replace engine oil and oil filter<sup>1</sup>
- Clean air conditioner filter (IS 250)
- Inspect engine air filter<sup>2</sup>
- Inspect nuts and bolts on chassis<sup>2</sup>
- Re-torque axle shaft flange bolts (all models except ES)
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:
 

<input type="checkbox"/> Axle shaft boots	<input type="checkbox"/> Front differential oil (AWD GS 300, AWD IS 250)
<input type="checkbox"/> Ball joints and dust covers	<input type="checkbox"/> Rack and pinion assembly
<input type="checkbox"/> Body	<input type="checkbox"/> Rear differential oil (IS, GS 300, GS 430, LS 430, SC)
<input type="checkbox"/> Brake lines and hoses	<input type="checkbox"/> Steering linkage and boots
<input type="checkbox"/> Engine coolant <sup>3</sup>	
<input type="checkbox"/> Exhaust pipes and mountings	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

- <sup>1</sup> Reset the oil replacement reminder ("MAINT REQD") light after replacing engine oil, if vehicle is equipped with this light.
- <sup>2</sup> Required only if vehicle is operated primarily in desert, on dirt roads or while towing.
- <sup>3</sup> Replace only with Genuine Toyota Super Long-Life Coolant or similar high-quality non-silicate, non-amine, non-borate ethylene-glycol coolant with long-life hybrid organic acid technology (i.e., a combination of low phosphates and organic acids).

SCHEDULED MAINTENANCE LOG

**24 Months or 20,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Measure thickness of front brake pads and rotors (GS 430, IS)
- Replace air conditioner filter (GS 300, GS 430, IS 350, LS 430, SC)
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

**30 Months or 25,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

## SCHEDULED MAINTENANCE LOG

M A I N T E N A N C E

### 36 Months or 30,000 Miles

- Replace engine oil and oil filter<sup>1</sup>
- Inspect nuts and bolts on chassis<sup>2</sup>
- Measure brake pad thickness and rotor runout
- Measure thickness of brake rotors (GS 430, IS)
- Replace air conditioner filter
- Replace brake fluid
- Replace engine air filter
- Re-torque axle shaft flange bolts (all models except ES)
- Rotate tires (all models except IS with different size front and rear tires)
- Road-test vehicle
- Inspect the following:
 

<ul style="list-style-type: none"> <li>___ Axle shaft boots</li> <li>___ Ball joints and dust covers</li> <li>___ Body</li> <li>___ Brake lines and hoses</li> <li>___ Engine coolant<sup>3</sup></li> <li>___ Exhaust pipes and mountings</li> <li>___ Front differential oil (AWD GS 300, AWD IS 250)</li> </ul>	<ul style="list-style-type: none"> <li>___ Fuel lines and connections, fuel tank band and fuel tank vapor vent system hoses</li> <li>___ Fuel tank cap gasket</li> <li>___ Manual transmission oil (IS 250)</li> <li>___ Rack and pinion assembly</li> <li>___ Rear differential oil (IS, GS, LS, SC)</li> <li>___ Steering linkage and boots</li> <li>___ Transmission fluid (ES 330, SC)</li> </ul>
--	---

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

- <sup>1</sup> Reset the oil replacement reminder ("MAINT REQD") light after replacing engine oil, if vehicle is equipped with this light.
- <sup>2</sup> Required only if vehicle is operated primarily in desert, on dirt roads or while towing.
- <sup>3</sup> Replace only with Genuine Toyota Super Long-Life Coolant or similar high-quality non-silicate, non-amine, non-borate ethylene-glycol coolant with long-life hybrid organic acid technology (i.e., a combination of low phosphates and organic acids).

*S c h e d u l e d   M a i n t e n a n c e   L o g*

SCHEDULED MAINTENANCE LOG

**42 Months or 35,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>
  - Axle shaft boots
  - Ball joints and dust covers
  - Engine air filter
  - Nuts and bolts on chassis
  - Steering linkage and boots

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

**48 Months or 40,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Measure thickness of front brake pads and rotors (GS 430, IS)
- Replace air conditioner filter (GS 300, GS 430, IS 350, LS 430, SC)
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>
  - Axle shaft boots
  - Ball joints and dust covers
  - Engine air filter
  - Nuts and bolts on chassis
  - Steering linkage and boots

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

## SCHEDULED MAINTENANCE LOG

M A I N T E N A N C E

### 54 Months or 45,000 Miles

- Replace engine oil and oil filter<sup>1</sup>
- Clean air conditioner filter (IS 250)
- Inspect engine air filter<sup>2</sup>
- Inspect nuts and bolts on chassis<sup>2</sup>
- Re-torque axle shaft flange bolts (all models except ES)
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:
  - \_\_\_ Axle shaft boots
  - \_\_\_ Ball joints and dust covers
  - \_\_\_ Body
  - \_\_\_ Brake lines and hoses
  - \_\_\_ Engine coolant<sup>3</sup>
  - \_\_\_ Exhaust pipes and mountings
  - \_\_\_ Front differential oil (AWD GS 300, AWD IS 250)
  - \_\_\_ Rack and pinion assembly
  - \_\_\_ Rear differential oil (IS, GS 300, GS 430, LS 430, SC)
  - \_\_\_ Steering linkage and boots

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

- <sup>1</sup> Reset the oil replacement reminder ("MAINT REQD") light after replacing engine oil, if vehicle is equipped with this light.
- <sup>2</sup> Required only if vehicle is operated primarily in desert, on dirt roads or while towing.
- <sup>3</sup> Replace only with Genuine Toyota Super Long-Life Coolant or similar high-quality non-silicate, non-amine, non-borate ethylene-glycol coolant with long-life hybrid organic acid technology (i.e., a combination of low phosphates and organic acids).

Scheduled Maintenance Log

SCHEDULED MAINTENANCE LOG

**60 Months or 50,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Measure thickness of front brake pads and rotors (GS 430, IS)
- Replace air conditioner filter (GS 300, GS 430, IS 350, LS 430, SC)
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

**66 Months or 55,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:



## SCHEDULED MAINTENANCE LOG

M A I N T E N A N C E

### 72 Months or 60,000 Miles

- |  |   |
|--|---|
| <input type="checkbox"/> Replace engine oil and oil filter <sup>1</sup><br><input type="checkbox"/> Measure brake pad thickness and rotor runout<br><input type="checkbox"/> Measure thickness of brake rotors (GS 430, IS)<br><input type="checkbox"/> Replace brake fluid<br><input type="checkbox"/> Replace engine air filter<br><input type="checkbox"/> Replace spark plugs (GS 300, IS) <sup>5</sup><br><input type="checkbox"/> Replace transmission fluid (ES 330, LS 430) <sup>3</sup><br><input type="checkbox"/> Re-torque axle shaft flange bolts (all models except ES)<br><input type="checkbox"/> Rotate tires (all models except IS with different size front and rear tires)<br><input type="checkbox"/> Road-test vehicle<br><input type="checkbox"/> Inspect the following:<br>___ Axle shaft boots<br>___ Ball joints and dust covers<br>___ Body<br>___ Brake lines and hoses<br>___ Drive belts<br>___ Engine coolant <sup>6</sup><br>___ Engine valve clearance (ES, GS 430, LS, SC)<br>___ Exhaust pipes and mountings<br>___ Front differential oil (AWD GS 300, AWD IS 250) | <input type="checkbox"/> Inspect nuts and bolts on chassis <sup>2</sup><br><input type="checkbox"/> Replace air conditioner filter<br><input type="checkbox"/> Replace differential oil (ES 330 <sup>3</sup> , IS <sup>4</sup> )<br><br>___ Fuel lines and connections, fuel tank band and fuel tank vapor vent system hoses<br>___ Fuel tank cap gasket<br>___ Manual transmission oil (IS 250)<br>___ Rack and pinion assembly<br>___ Rear differential oil (IS, GS, LS, SC)<br>___ Steering linkage and boots<br>___ Transmission fluid (ES 330, SC) |
|--|---|

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

- <sup>1</sup> Reset the oil replacement reminder ("MAINT REQD") light after replacing engine oil, if vehicle is equipped with this light.
- <sup>2</sup> Required only if vehicle is operated primarily in desert, on dirt roads or while towing.
- <sup>3</sup> Required only if vehicle is operated primarily while towing.
- <sup>4</sup> If equipped with limited-slip differential.
- <sup>5</sup> Required under the terms of the Emission Control Warranty.
- <sup>6</sup> Replace only with Genuine Toyota Super Long-Life Coolant or similar high-quality non-silicate, non-amine, non-borate ethylene-glycol coolant with long-life hybrid organic acid technology (i.e., a combination of low phosphates and organic acids).

*S c h e d u l e d   M a i n t e n a n c e   L o g*

SCHEDULED MAINTENANCE LOG

**78 Months or 65,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

**84 Months or 70,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Measure thickness of front brake pads and rotors (GS 430, IS)
- Replace air conditioner filter (GS 300, GS 430, IS 350, LS 430, SC)
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

## SCHEDULED MAINTENANCE LOG

### 90 Months or 75,000 Miles

- Replace engine oil and oil filter<sup>1</sup>
- Clean air conditioner filter (IS 250)
- Inspect engine air filter<sup>2</sup>
- Inspect nuts and bolts on chassis<sup>2</sup>
- Re-torque axle shaft flange bolts (all models except ES)
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:
 

<input type="checkbox"/> Axle shaft boots	<input type="checkbox"/> Front differential oil (AWD GS 300, AWD IS 250)
<input type="checkbox"/> Ball joints and dust covers	<input type="checkbox"/> Rack and pinion assembly
<input type="checkbox"/> Body	<input type="checkbox"/> Rear differential oil (IS, GS 300, GS 430, LS 430, SC)
<input type="checkbox"/> Brake lines and hoses	<input type="checkbox"/> Steering linkage and boots
<input type="checkbox"/> Drive belts	
<input type="checkbox"/> Engine coolant <sup>3</sup>	
<input type="checkbox"/> Exhaust pipes and mountings	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

- <sup>1</sup> Reset the oil replacement reminder ("MAINT REQD") light after replacing engine oil, if vehicle is equipped with this light.
- <sup>2</sup> Required only if vehicle is operated primarily in desert, on dirt roads or while towing.
- <sup>3</sup> Replace only with Genuine Toyota Super Long-Life Coolant or similar high-quality non-silicate, non-amine, non-borate ethylene-glycol coolant with long-life hybrid organic acid technology (i.e., a combination of low phosphates and organic acids).

SCHEDULED MAINTENANCE LOG

**96 Months or 80,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Measure thickness of front brake pads and rotors (GS 430, IS)
- Replace air conditioner filter (GS 300, GS 430, IS 350, LS 430, SC)
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

**102 Months or 85,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

## SCHEDULED MAINTENANCE LOG

M A I N T E N A N C E

### 108 Months or 90,000 Miles

- Replace engine oil and oil filter<sup>1</sup>
- Inspect nuts and bolts on chassis<sup>2</sup>
- Measure brake pad thickness and rotor runout
- Measure thickness of brake rotors (GS 430, IS)
- Replace air conditioner filter
- Replace brake fluid
- Replace engine air filter
- Replace timing belt (ES, GS 430, LS, SC)
- Re-torque axle shaft flange bolts (all models except ES)
- Rotate tires (all models except IS with different size front and rear tires)
- Road-test vehicle
- Inspect the following:
 

<ul style="list-style-type: none"> <li>___ Axle shaft boots</li> <li>___ Ball joints and dust covers</li> <li>___ Body</li> <li>___ Brake lines and hoses</li> <li>___ Engine coolant<sup>3</sup></li> <li>___ Exhaust pipes and mountings</li> <li>___ Front differential oil (AWD GS 300, AWD IS 250)</li> </ul>	<ul style="list-style-type: none"> <li>___ Fuel lines and connections, fuel tank band and fuel tank vapor vent system hoses</li> <li>___ Fuel tank cap gasket</li> <li>___ Manual transmission oil (IS 250)</li> <li>___ Rack and pinion assembly</li> <li>___ Rear differential oil (IS, GS, LS, SC)</li> <li>___ Steering linkage and boots</li> <li>___ Transmission fluid (ES 330, SC)</li> </ul>
--	---

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

- <sup>1</sup> Reset the oil replacement reminder ("MAINT REQD") light after replacing engine oil, if vehicle is equipped with this light.
- <sup>2</sup> Required only if vehicle is operated primarily in desert, on dirt roads or while towing.
- <sup>3</sup> Replace only with Genuine Toyota Super Long-Life Coolant or similar high-quality non-silicate, non-amine, non-borate ethylene-glycol coolant with long-life hybrid organic acid technology (i.e., a combination of low phosphates and organic acids).

*S c h e d u l e d   M a i n t e n a n c e   L o g*

SCHEDULED MAINTENANCE LOG

**114 Months or 95,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

**120 Months or 100,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>       Replace engine coolant<sup>3</sup>
- Measure thickness of front brake pads and rotors (GS 430, IS)
- Replace air conditioner filter (GS 300, GS 430, IS 350, LS 430, SC)
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

## SCHEDULED MAINTENANCE LOG

### 126 Months or 105,000 Miles

- Replace engine oil and oil filter<sup>1</sup>
- Clean air conditioner filter (IS 250)
- Inspect engine air filter<sup>2</sup>
- Inspect nuts and bolts on chassis<sup>2</sup>
- Re-torque axle shaft flange bolts (all models except ES)
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:
  - \_\_\_ Axle shaft boots
  - \_\_\_ Ball joints and dust covers
  - \_\_\_ Body
  - \_\_\_ Brake lines and hoses
  - \_\_\_ Exhaust pipes and mountings
  - \_\_\_ Front differential oil (AWD GS 300, AWD IS 250)
  - \_\_\_ Rack and pinion assembly
  - \_\_\_ Rear differential oil (IS, GS 300, GS 430, LS 430, SC)
  - \_\_\_ Steering linkage and boots

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

<sup>1</sup> Reset the oil replacement reminder ("MAINT REQD") light after replacing engine oil, if vehicle is equipped with this light.

<sup>2</sup> Required only if vehicle is operated primarily in desert, on dirt roads or while towing.

<sup>3</sup> Replace only with Genuine Toyota Super Long-Life Coolant or similar high-quality non-silicate, non-amine, non-borate ethylene-glycol coolant with long-life hybrid organic acid technology (i.e., a combination of low phosphates and organic acids).

SCHEDULED MAINTENANCE LOG

**132 Months or 110,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Measure thickness of front brake pads and rotors (GS 430, IS)
- Replace air conditioner filter (GS 300, GS 430, IS 350, LS 430, SC)
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

**138 Months or 115,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Inspect engine coolant<sup>3</sup>
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:



## SCHEDULED MAINTENANCE LOG

M A I N T E N A N C E

### 144 Months or 120,000 Miles

- |   |  |
|---|--|
| <input type="checkbox"/> Replace engine oil and oil filter <sup>1</sup>                               | <input type="checkbox"/> Inspect nuts and bolts on chassis <sup>2</sup>                    |
| <input type="checkbox"/> Measure brake pad thickness and rotor runout                                 | <input type="checkbox"/> Replace air conditioner filter                                    |
| <input type="checkbox"/> Measure thickness of brake rotors (GS 430, IS)                               | <input type="checkbox"/> Replace differential oil (ES 330 <sup>4</sup> , IS <sup>5</sup> ) |
| <input type="checkbox"/> Replace brake fluid  |  |
| <input type="checkbox"/> Replace engine air filter  |  |
| <input type="checkbox"/> Replace spark plugs <sup>6</sup>   |  |
| <input type="checkbox"/> Replace transmission fluid (ES 330, LS 430) <sup>4</sup>                     |  |
| <input type="checkbox"/> Re-torque axle shaft flange bolts (all models except ES)                     |  |
| <input type="checkbox"/> Rotate tires (all models except IS with different size front and rear tires) |  |
| <input type="checkbox"/> Road-test vehicle  |  |
| <input type="checkbox"/> Inspect the following:   |  |
| ___ Axle shaft boots  | ___ Fuel lines and connections, fuel tank band and fuel tank vapor vent system hoses       |
| ___ Ball joints and dust covers   | ___ Fuel tank cap gasket   |
| ___ Body  | ___ Manual transmission oil (IS 250)   |
| ___ Brake lines and hoses   | ___ Rack and pinion assembly   |
| ___ Drive belts   | ___ Rear differential oil (IS, GS, LS, SC)   |
| ___ Engine valve clearance (ES, GS 430, LS, SC)   | ___ Steering linkage and boots   |
| ___ Exhaust pipes and mountings   | ___ Transmission fluid (ES 330, SC)  |
| ___ Front differential oil (AWD GS 300, AWD IS 250)   |  |

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

- <sup>1</sup> Reset the oil replacement reminder ("MAINT REQD") light after replacing engine oil, if vehicle is equipped with this light.
- <sup>2</sup> Required only if vehicle is operated primarily in desert, on dirt roads or while towing.
- <sup>3</sup> Replace only with Genuine Toyota Super Long-Life Coolant or similar high-quality non-silicate, non-amine, non-borate ethylene-glycol coolant with long-life hybrid organic acid technology (i.e., a combination of low phosphates and organic acids).
- <sup>4</sup> Required only if vehicle is operated primarily while towing.
- <sup>5</sup> If equipped with limited-slip differential.
- <sup>6</sup> Required under the terms of the Emission Control Warranty.

SCHEDULED MAINTENANCE LOG

**150 Months or 125,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

**156 Months or 130,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Inspect engine coolant<sup>3</sup>
- Measure thickness of front brake pads and rotors (GS 430, IS)
- Replace air conditioner filter (GS 300, GS 430, IS 350, LS 430, SC)
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

## SCHEDULED MAINTENANCE LOG

M A I N T E N A N C E

### 162 Months or 135,000 Miles

- Replace engine oil and oil filter<sup>1</sup>
- Clean air conditioner filter (IS 250)
- Inspect engine air filter<sup>2</sup>
- Inspect nuts and bolts on chassis<sup>2</sup>
- Re-torque axle shaft flange bolts (all models except ES)
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:
  - \_\_\_ Axle shaft boots
  - \_\_\_ Ball joints and dust covers
  - \_\_\_ Body
  - \_\_\_ Brake lines and hoses
  - \_\_\_ Drive belts
  - \_\_\_ Exhaust pipes and mountings
  - \_\_\_ Front differential oil (AWD GS 300, AWD IS 250)
  - \_\_\_ Rack and pinion assembly
  - \_\_\_ Rear differential oil (IS, GS 300, GS 430, LS 430, SC)
  - \_\_\_ Steering linkage and boots

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

- <sup>1</sup> Reset the oil replacement reminder ("MAINT REQD") light after replacing engine oil, if vehicle is equipped with this light.
- <sup>2</sup> Required only if vehicle is operated primarily in desert, on dirt roads or while towing.
- <sup>3</sup> Replace only with Genuine Toyota Super Long-Life Coolant or similar high-quality non-silicate, non-amine, non-borate ethylene-glycol coolant with long-life hybrid organic acid technology (i.e., a combination of low phosphates and organic acids).

Scheduled Maintenance Log

15

SCHEDULED MAINTENANCE LOG

**168 Months or 140,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Measure thickness of front brake pads and rotors (GS 430, IS)
- Replace air conditioner filter (GS 300, GS 430, IS 350, LS 430, SC)
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

**174 Months or 145,000 Miles**

- Replace engine oil and oil filter<sup>1</sup>
- Inspect engine coolant<sup>3</sup>
- Re-torque axle shaft flange bolts (all models except ES)<sup>2</sup>
- Rotate tires (all models except IS with different size front and rear tires)
- Visually inspect brake pads and rotors
- Road-test vehicle
- Inspect the following:<sup>2</sup>

___ Axle shaft boots	___ Nuts and bolts on chassis
___ Ball joints and dust covers	___ Steering linkage and boots
___ Engine air filter	

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

## SCHEDULED MAINTENANCE LOG

M A I N T E N A N C E

### 180 Months or 150,000 Miles

- Replace engine oil and oil filter<sup>1</sup>
- Inspect nuts and bolts on chassis<sup>2</sup>
- Measure brake pad thickness and rotor runout
- Measure thickness of brake rotors (GS, 430, IS)
- Replace air conditioner filter
- Replace brake fluid
- Replace engine air filter
- Replace engine coolant<sup>3</sup>
- Re-torque axle shaft flange bolts (all models except ES)
- Rotate tires (all models except IS with different size front and rear tires)
- Road-test vehicle
- Inspect the following:
 

<ul style="list-style-type: none"> <li>___ Axle shaft boots</li> <li>___ Ball joints and dust covers</li> <li>___ Body</li> <li>___ Brake lines and hoses</li> <li>___ Drive belts</li> <li>___ Exhaust pipes and mountings</li> <li>___ Front differential oil (AWD GS 300, AWD IS 250)</li> </ul>	<ul style="list-style-type: none"> <li>___ Fuel lines and connections, fuel tank band and fuel tank vapor vent system hoses</li> <li>___ Fuel tank cap gasket</li> <li>___ Manual transmission oil (IS 250)</li> <li>___ Rack and pinion assembly</li> <li>___ Rear differential oil (IS, GS, LS, SC)</li> <li>___ Steering linkage and boots</li> <li>___ Transmission fluid (ES 330, SC)</li> </ul>
---	---

Date: \_\_\_\_\_ Mileage: \_\_\_\_\_

Notes:

- <sup>1</sup> Reset the oil replacement reminder ("MAINT REQD") light after replacing engine oil, if vehicle is equipped with this light.
- <sup>2</sup> Required only if vehicle is operated primarily in desert, on dirt roads or while towing.
- <sup>3</sup> Replace only with Genuine Toyota Super Long-Life Coolant or similar high-quality non-silicate, non-amine, non-borate ethylene-glycol coolant with long-life hybrid organic acid technology (i.e., a combination of low phosphates and organic acids).

*S c h e d u l e d   M a i n t e n a n c e   L o g*

## EXPLANATION OF MAINTENANCE ITEMS

The following descriptions are provided to give you a better understanding of the maintenance services that should be performed on your vehicle. The scheduled maintenance log indicates at which time/mileage intervals each service should be performed. Please note that many maintenance services should be performed only by a qualified technician.

For further information on maintenance services that you can perform yourself, see the “Service Procedures and Specifications” section of your *Owner’s Manual*.

**Air Conditioner Filter**

Refer to your *Owner’s Manual* for service details.

**Axle Shaft Boots**

At driven wheels, check the axle shaft boots and clamps for cracks, deterioration and damage. Replace any damaged parts and, if necessary, repack the grease. Re-torque the axle shaft flange bolts at the indicated intervals. A qualified technician should perform these operations.

**Ball Joints and Dust Covers**

Check the suspension and steering linkage ball joints for looseness and damage. Check all dust covers for deterioration and damage. A qualified technician should perform these inspections.

**Body Inspection**

Visually check for corrosion, scratches and other damage. Check outer body panels, inner panels of the hood and doors, and underneath the vehicle. Apply touch-up paint to any chips and scratches or have them repaired by a qualified technician.

## EXPLANATION OF MAINTENANCE ITEMS

### Brake Fluid

Replace using fluid type specified in your *Owner's Manual*. A qualified technician should perform this operation.

### Brake Lines and Hoses

Visually inspect for proper installation. Check for chafing, cracks, deterioration and signs of leakage. Replace any deteriorated or damaged parts. A qualified technician should perform these operations.

### Brake Linings/Drums and Brake Pads/Rotors

Check the parking brake linings (shoes) and drums for scoring, burning, fluid leakage, broken parts and excessive wear. Check brake pads and rotors for excessive wear; check brake rotors for runout. Check brake calipers for fluid leakage. A qualified technician should perform these inspections.

### Charcoal Canister

Check for internal damage and clogging. If necessary, clean with compressed air or replace. A qualified technician should perform these operations.

### Differential Oil

Check for correct oil level and inspect each differential component for signs of leakage. If you discover any leakage, have it repaired by a qualified technician immediately. Refer to your *Owner's Manual* for fluid specifications.

### Drive Belts

Inspect for cracks, excessive wear and oiliness. Check the belt tension and adjust if necessary. Replace the belts if they are damaged.

### Engine Air Filter

Check for damage, excessive wear and oiliness. Replace if necessary.

### Engine Coolant

Drain and flush the cooling system and refill with Genuine Toyota Super Long-Life Coolant or similar high-quality non-silicate, non-amine, non-borate ethylene-glycol coolant with long-life hybrid organic acid technology (i.e., a combination of low phosphates

## EXPLANATION OF MAINTENANCE ITEMS

and organic acids). A qualified technician should perform this operation.

**Note:** Initial replacement is at 120 months/100,000 miles. Replace every 60 months/50,000 miles thereafter.

**Engine Oil and Oil Filter**

Replace the oil filter and drain and refill the engine oil at specified intervals. For recommended oil grade and viscosity, refer to your *Owner's Manual*. Some models are equipped with a replaceable oil filter element and oil filter cap O-ring; replace both at each oil change. Refer to your *Owner's Manual*.

**Engine Valve Clearance (except GS 300 and IS)**

Inspect for excessive lifter noise and engine vibration and adjust if necessary. A qualified technician should perform this operation. (The GS 300 and IS are equipped with hydraulic valve lash adjusters, which require no periodic clearance inspection or adjustment.)

**Exhaust Pipes and Mountings**

Visually inspect the exhaust pipes, muffler and hangers for cracks, deterioration and damage. Start the engine and listen carefully for any exhaust gas leakage. Tighten connections or replace parts as necessary.

**Fuel Lines and Connections, Fuel Tank Band and Fuel Tank Vapor Vent System Hoses**

Visually inspect for corrosion, damage, cracks and loose or leaking connections. Tighten connections or replace parts as necessary.

**Fuel Tank Cap Gasket**

Visually inspect for cracks, deterioration and damage and replace if necessary.

**Nuts and Bolts on Chassis**

Re-tighten the seat mounting bolts and front/rear suspension member retaining bolts to specified torque.



## EXPLANATION OF MAINTENANCE ITEMS

### Rack and Pinion Assembly

Inspect the rack and pinion assembly for signs of leakage, damage and loose electrical connections. Tighten connections and if you discover any leakage or damage, have it repaired immediately by a qualified technician.

### Road Test

While driving the vehicle, check for proper operation of engine, transmission, brakes and steering. Also check for abnormal noise or vibration from any part of the vehicle.

### Spark Plugs

Install new plugs of the same type as originally equipped. Refer to your *Owner's Manual*. A qualified technician should perform this operation.

### Steering Linkage and Boots

With the vehicle stopped, check for excessive freeplay in the steering wheel. Inspect the linkage for bending and damage and the dust boots for deterioration,

cracks and damage. Replace any damaged parts. A qualified technician should perform these operations.

### Timing Belt (except GS 300 and IS)

Replace every 90,000 miles or 108 months. A qualified technician should perform this operation. (The GS 300 and IS are equipped with a timing chain, which requires no periodic inspection.)

### Tire Rotation

Tires should be rotated according to the instructions in your *Owner's Manual*. When rotating tires, check pressure and check for damage and uneven wear. If the spare is not rotated, check the condition and pressure of the spare.

### Transfer Case Fluid (GS 300 All-Wheel Drive, IS 250 All-Wheel Drive)

Periodic fluid checks and replacement of the transfer case fluid are not required. Any repairs that require adding or replacing fluid should be performed by a qualified technician following procedures in Lexus service and repair publications.

## EXPLANATION OF MAINTENANCE ITEMS

**Transmission Fluid**

Check for correct fluid level and inspect each transmission component for signs of leakage. If you discover any leakage, have it repaired by a qualified technician immediately.

**Note:** On the LS 430, GS and IS, the transmission and transmission fluid are a completely sealed unit. Therefore, periodic checks and replacement of the transmission fluid are not required, and there is no dipstick on the transmission on these vehicles. Any repairs that require adding or replacing fluid should be performed by a qualified technician following procedures in Lexus service and repair publications.

**Variable Gear Ratio Steering Assembly (GS 430)**

Inspect the variable gear ratio steering assembly for damage and loose electrical connections. Tighten connections and if you discover any damage, have it repaired immediately by a qualified technician.

VEHICLE IDENTIFICATION

Model \_\_\_\_\_ Body style \_\_\_\_\_

In-service date \_\_\_\_\_ Mileage at delivery \_\_\_\_\_

Selling dealership \_\_\_\_\_ Selling dealership phone number \_\_\_\_\_

Key number \_\_\_\_\_

Vehicle Identification Number \_\_\_\_\_

M A I N T E N A N C E

**M A I N T E N A N C E**

NOTES

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

NOTES


**M A I N T E N A N C E**



## Owner Information Change Form

If your name or address has changed or if you purchased your Lexus as a used vehicle, please complete and mail one of the attached cards, even if your warranty coverage has expired. This will enable Lexus to contact you with important product or safety updates concerning your vehicle. If there is no longer a card attached, please call the Lexus Customer Satisfaction Department at (800) 255-3987.

**Check one:**

- Same owner, name and/or address changed
- Same owner, additional driver who should receive product/safety updates
- New owner, purchased vehicle used from a Lexus dealership on this date: \_\_\_\_\_
- New owner, purchased vehicle used from other than a Lexus dealership on this date: \_\_\_\_\_

**FBC**

Vehicle Identification Number (required to process change)

Today's date:    Mo.    Day    Year

- Mr.     Mrs.     Ms.     Miss     Dr.

First name    M.I.    Last name

Company name    Check here if address below is for company:

Street address or P.O. Box    Apt. or suite number


City    State    Zip code

Primary phone number    Secondary phone number

E-mail address: \_\_\_\_\_

This information is obtained solely for the use of Lexus. Lexus occasionally sends special promotional offers to registered owners. Check here if you prefer not to receive these offers.






NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

**BUSINESS REPLY MAIL**  
FIRST-CLASS MAIL PERMIT NO. 449 TORRANCE, CA

POSTAGE WILL BE PAID BY THE ADDRESSEE

LEXUS  
L202  
ATTN: CUSTOMER SATISFACTION  
PO BOX 2991  
TORRANCE CA 90509-9975



TOY-TQ001-00002228



## Owner Information Change Form

If your name or address has changed or if you purchased your Lexus as a used vehicle, please complete and mail one of the attached cards, even if your warranty coverage has expired. This will enable Lexus to contact you with important product or safety updates concerning your vehicle. If there is no longer a card attached, please call the Lexus Customer Satisfaction Department at (800) 255-3987.

**Check one:**

- Same owner, name and/or address changed
- Same owner, additional driver who should receive product/safety updates
- New owner, purchased vehicle used from a Lexus dealership on this date: \_\_\_\_\_
- New owner, purchased vehicle used from other than a Lexus dealership on this date: \_\_\_\_\_



Vehicle Identification Number (required to process change)

Today's date: Mo. Day Year

- Mr.    Mrs.    Ms.    Miss    Dr.

First name   M.I.   Last name

Company name

Check here if address below is for company:

Street address or P.O. Box   Apt. or suite number


City   State   Zip code

Primary phone number   Secondary phone number

E-mail address: \_\_\_\_\_

This information is obtained solely for the use of Lexus. Lexus occasionally sends special promotional offers to registered owners. Check here if you prefer not to receive these offers.






NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

**BUSINESS REPLY MAIL**  
FIRST-CLASS MAIL PERMIT NO. 449 TORRANCE, CA

POSTAGE WILL BE PAID BY THE ADDRESSEE

LEXUS  
L202  
ATTN: CUSTOMER SATISFACTION  
PO BOX 2991  
TORRANCE CA 90509-9975







THE PASSIONATE PURSUIT OF PERFECTION.

00505-06LWB

7/05