

180L Slow Return To Idle  
Go And See Action List

Action / Description	Results
Document environmental conditions (Temperature, Humidity, Etc...)	
Evaluate and understand complaint from customer	
Actuate by hand to verify slow return condition can be repeated	
Remove bearing cover and verify shaft is rotating in bearing freely	
Disengage friction device using CTS tool and determine if pedal still returns slowly	
Remove from dash panel, actuate by hand and determine if pedal still returns slowly	
Evaluate vehicle dash panel for obstructions (after market floor mats)	
Mount to another vehicle or flat surface, actuate by hand and determine if pedal still returns slowly	
Remove Bottom Cover and look for any abnormalities (friction lever engagement, magnet, etc...)	
Return pedal to CTS for analysis	

[AF]